

Super Vision3.0

I/O No.	NAME	I/O No.	NAME	I/O No.	NAME	I/O No.	NAME	I/O No.	NAME
X00		X20		X040	手動モードPB	Y060	手動モードPB-LP	X080	
X01		X21		X041	自動モードPB	Y061	自動モードPB-LP	X081	
X02		X22		X042	運転スタートPB	Y062	運転スタートPB-LP	X082	
X03		X23		X043	運転ストップPB	Y063	運転ストップPB-LP	X083	
X04		X24		X044	運転準備ON	Y064	運転準備ON-LP	X084	
X05		X25		X045	リセットPB	Y065	リセット PB-LP	X085	
X06		X26		X046	実行 PB	Y066	実行 PB-LP	X088	
X07		X27		X047		Y067		X087	
X08		X28		X048		Y068		X088	
X09		X29		X049		Y069		X089	
X0A		X2A		X04A		Y06A		X08A	
X0B		X2B		X04B		Y06B		X08B	
X0C		X2C		X04C		Y06C		X08C	
X0D		X2D		X04D		Y06D		X08D	
X0E		X2E		X04E		Y06E		X08E	
X0X		X2F		X04F		Y06F		X08F	
X10		X30		X050		Y070		X090	
X11		X31		X051		Y071		X091	
X12		X32		X052		Y072		X092	
X13		X33		X053		Y073		X093	
X14		X34		X054		Y074		X094	
X15		X35		X055		Y075		X095	
X16		X36		X056		Y076		X098	
X17		X37		X057		Y077		X099	
X18		X38		X058		Y078		X098	
X19		X39		X059		Y079		X099	
X1A		X3A		X05A		Y07A		X09A	
X1B		X3B		X05B		Y07B		X09B	
X1C		X3C		X05C		Y07C		X09C	
X1D		X3D		X05D		Y07D		X09D	
X1E		X3E		X05E		Y07E		X09E	
X1F		X3F		X05F	制御電源ON	Y07F		X09F	

					SHEETMATIC	Drawing type	INPUT/OUTPUT LIST	Order number	
--	--	--	--	--	------------	--------------	-------------------	--------------	--

Super Vision3.0

I/O No.	NAME	I/O No.	NAME	I/O No.	NAME	I/O No.	NAME	I/O No.	NAME
X1000		X1020		X1040		X1060		X1080	
X1001		X1021		X1041		X1061		X1081	
X1002		X1022		X1042		X1062		X1082	
X1003		X1023		X1043		X1063		X1083	
X1004		X1024		X1044		X1064		X1084	
X1005		X1025		X1045		X1065		X1085	
X1006		X1026		X1046		X1066		X1088	
X1007		X1027		X1047		X1067		X1087	
X1008		X1028		X1048		X1068		X1088	
X1009		X1029		X1049		X1069		X1089	
X100A		X102A		X104A		X106A		X108A	
X100B		X102B		X104B		X106B		X108B	
X100C		X102C		X104C		X106C		X108C	
X100D		X102D		X104D		X106D		X108D	
X100E		X102E		X104E		X106E		X108E	
X100F		X102F		X104F		X106F		X108F	
X1010		X1030		X1050		X1070		X1090	
X1011		X1031		X1051		X1071		X1091	
X1012		X1032		X1052		X1072		X1092	
X1013		X1033		X1053		X1073		X1093	
X1014		X1034		X1054		X1074		X1094	
X1015		X1035		X1055		X1075		X1095	
X1016		X1036		X1056		X1076		X1098	
X1017		X1037		X1057		X1077		X1099	
X1018		X1038		X1058		X1078		X1098	
X1019		X1039		X1059		X1079		X1099	
X101A		X103A		X105A		X107A		X109A	
X101B		X103B		X105B		X107B		X109B	
X101C		X103C		X105C		X107C		X109C	
X101D		X103D		X105D		X107D		X109D	
X101E		X103E		X105E		X107E		X109E	
X101F		X103F		X105F		X107F		X109F	

--	--	--	--

--	--	--	--	--	--	--	--	--	--

SHEETMATIC

Drawing type

INPUT/OUTPUT LIST

Order number

Super Vision3.0

I/O No.	NAME	I/O No.	NAME	I/O No.	NAME	I/O No.	NAME	I/O No.	NAME
Y1000		Y1020		Y1040	S3 自動モード指令	Y1060		Y1080	
Y1001		Y1021		Y1041		Y1061		Y1081	
Y1002		Y1022		Y1042		Y1062		Y1082	
Y1003		Y1023		Y1043		Y1063		Y1083	
Y1004		Y1024		Y1044		Y1064		Y1084	
Y1005		Y1025		Y1045		Y1065		Y1085	
Y1006		Y1026		Y1046		Y1066		Y1088	
Y1007		Y1027		Y1047		Y1067		Y1087	
Y1008		Y1028		Y1048		Y1068		Y1088	
Y1009		Y1029		Y1049		Y1069		Y1089	
Y100A		Y102A		Y104A		Y106A		Y108A	
Y100B		Y102B		Y104B		Y106B		Y108B	
Y100C		Y102C		Y104C		Y106C		Y108C	
Y100D		Y102D		Y104D		Y106D		Y108D	
Y100E		Y102E		Y104E		Y106E		Y108E	
Y100F		Y102F		Y104F		Y106F		Y108F	
Y1010		Y1030		Y1050		Y1070		Y1090	
Y1011		Y1031		Y1051		Y1071		Y1091	
Y1012		Y1032		Y1052		Y1072		Y1092	
Y1013		Y1033		Y1053		Y1073		Y1093	
Y1014		Y1034		Y1054		Y1074		Y1094	
Y1015		Y1035		Y1055		Y1075		Y1095	
Y1016		Y1036		Y1056		Y1076		Y1098	
Y1017		Y1037		Y1057		Y1077		Y1099	
Y1018		Y1038		Y1058		Y1078		Y1098	
Y1019		Y1039		Y1059		Y1079		Y1099	
Y101A		Y103A		Y105A		Y107A		Y109A	
Y101B		Y103B		Y105B		Y107B		Y109B	
Y101C		Y103C		Y105C		Y107C		Y109C	
Y101D		Y103D		Y105D		Y107D		Y109D	
Y101E		Y103E		Y105E		Y107E		Y109E	
Y101F		Y103F		Y105F		Y107F		Y109F	

--	--	--	--	--	--	--	--	--	--

					SHEETMATIC	Drawing type	INPUT/OUTPUT LIST	Order number		
--	--	--	--	--	------------	--------------	-------------------	--------------	--	--